

DAVE ROSS (408) 761-5882 <u>dave@sewerlock.com</u>

OPERATION

OPERATION & MAINTENANCE MANUAL

SEWER – STORM – WATER - UTILITY SECURITY - INFLOW REDUCTION – ODOR CONTROL

> Installed in New and Existing MH Fits All Maintenance Holes



1) REMOVE CAST IRON COVER.



2) REMOVE PADLOCKS, TURN EYEBOLTS TO ALIGN WITH SLOTS IN INNER COVER, AND LIFT OUT THE INNER COVER.



3) WHEN WORK IS COMPLETE, ALIGN EYE BOLTS WITH THE SLOTS IN THE INNER COVER, REPLACE THE INNER COVER, AND SECURE THE PADLOCKS.



FOR MANHOLES WITH OPTIONAL ODOR CONTROL RING WITH PRESSURE SEAL, BEFORE REMOVING THE INNER COVER, AIR TEST FIRST USING THE BULKHEAD.

MAINTENANCE

Inspection (Semiannual) Cleaning (At time of Inspection) Lubricate or replace padlocks as needed. Safety (Follow current industry standards)

REVISED 9/10/13